



Part Number: 102-2501

Application: NISSAN 2.6L (RB26) INLINE 6

Installation Procedure

1. Due to the high torque value required, we recommend the use of a flywheel locking tool to prevent the crankshaft from rotating while torquing the damper bolt.
2. Clean and inspect all hardware prior to installation. Look for obvious defects or shipping damages. Please call 805-339-2200 with any questions or issues.
3. To ensure proper engagement and accurate torque readings, clean the female threads in the crankshaft.
4. Lubricate the bolt threads and underside of the bolt head with ARP Ultra-Torque Fastener Assembly Lubricant. Place the washer on the bolt then install into the crankshaft.
5. Confirm crankshaft is secure then torque the bolt to:

325 - 345 ft-lbs

If you have any questions or need additional information please contact us at (805) 339-2200 or by FAX at (805) 650-0742

Automotive Racing Products
1863 Eastman Ave. Ventura, Ca 93003

www.arp-bolts.com