



Part Number: 151-1001

**Application: FORD 2.3L DURATECH CAM
SPROCKET BOLT KIT**

Installation Procedure

- 1.** Clean and inspect all hardware prior to installation. Look for obvious defects or shipping damages. Please call 805-339-2200 with any questions or issues.
- 2.** To ensure proper engagement and accurate torque readings, clean the female threads.
- 3.** Lubricate the bolt threads and underside of the bolt head with ARP Ultra-Torque Fastener Assembly Lubricant.
- 4.** While keeping the camshaft from rotating, torque the bolts to:

50 ft-lbs

If you have any questions or need additional information please contact us at (805) 339-2200 or by FAX at (805) 650-0742

Automotive Racing Products
1863 Eastman Ave. Ventura, Ca 93003

www.arp-bolts.com